


ReelPRO

User Manual

Step 1 - Carefully unpack ReelPRO.

Step 2 - Verify parts list.



Step 3 - Assemble media flanges. Place slotted flange on drive system and secure with media flange clip. Place the other media flange on the media flange holder and secure with clip (place the provided washer behind the media flange).

Step 4 - Install drive system on printer stand.



Step 5 - Adjust bracket and tighten top and bottom set screws.



Top Set Screw

Bottom Set Screw

Step 5

Step 6 - Install media flange holder on printer stand.



Step 6

Step 7 - Insert core between media flanges ,adjust bracket and tighten top and bottom set screws.



Core provided by user

Step 7

Step 8 - Enjoy the ease of use when printing long jobs.



Step 9 - Operation



Forward - Left
Off - Center
Reverse - Right

110v Power Cord

Adjust to right for heavy loads, left for lighter loads

Product Specifications

- 110v Power Source
- For use with media weighing up to approximately 45 pounds

Operation / Safety

- Turn off ReelPRO when printer is not printing to avoid damage to drive motor and clutch
- Use caution to avoid getting hair, neckties, jewelry, etc.. caught in system when running
- Unplug system when installing or un-installing from printer
- If you're planning to run your ReelPRO unattended connect the device to a Light Timer which will turn off when the print job is complete. Leaving ReelPRO turned on without your printer running for extended periods of time can cause excessive wear to the motor and clutch systems.